



SmartCall Alert Watch Pager IStation



Message Color Key

- 1 – White
- 2 – Green
- 3 – Blue
- 4 – Red

Sending Messages from IStation Transmitter

Turn Preset Message On

Scroll on the menu to default and change the color to a desired one

Send Individual Messages/Colors

1. Press the pager # and ENTER
2. Press the color code number (1-4) then ENTER
3. Type the message then press SEND

Manage Messages on Watch

To View Message

Scroll to the left with your finger or press the side button

To Erase Messages

1. Hold the button down on the side of watch for 2-3 seconds
2. Scroll to DELETE or DELETE ALL
3. Press and hold the side button again for 2-3 seconds



Call today for more information
800.321.6221
www.jtech.com